

Formula Student Dämpfer mit Anbauteilen

Formula Student Damper with Additional Parts



Nadellagerkit (1St./Dämpfer)
Bestellnr.: 001770001914
Needle Bearing Kit (1pc./damper)
Order No.: 001770001914



F3 Federn
Di=36mm
Wir empfehlen
Federn von H&R
F3 Springs
Di=36mm
We recommend
springs from H&R



Formula Student Dämpfer
Bestellnr.: 881700007751 Setting FS 02
Formula Student Damper
Order No.: 881700007751 Setting FS 02

Bestellnr.: 881700011236 Setting FS 03
Formula Student Damper
Order No.: 881700011236 Setting FS 03